

INDUSTRIAL FLOOR TAPE

VS

INDUSTRIAL FLOOR PAINT

INSTALLATION



FLOOR TAPE

requires no extra install equipment



FLOOR PAINTING

can require a range of additional tools and products.



WAIT TIME

FLOOR TAPE

FLOOR PAINTING

DRY TIME  IMMEDIATE

3-8 HRS

CURE TIME  NONE

72+ hrs

Waiting for paint to dry can cause significant downtime and can sometimes shut down entire factory floors for days

Industrial floor tapes bond immediately after install, without having to wait for paint to dry.



DURABILITY

FLOOR TAPE

FLOOR PAINT

- Enhanced protection against:
 - Forklift**
 - Pallet Jacks**
 - Trucks**
 - Foot Traffic**
 - Chemicals**
- Easy to clean.
- Maintains appearance and durability over long periods.

- Fades and discolors quickly.
- Can be easily worn down by heavy foot traffic.
- Chips and cracking will appear over time, requiring repainting.



STOP PAINTING YOUR FLOORS!

USING
INDUSTRIAL
FLOOR TAPES

FREES TIME



SAVES MONEY



ELIMINATES
HEADACHES



UltraTape

Adhesive Tape & Labels for Critical Environments

Visit our website

WWW.CLEANROOMTAPE.COM

Find us on social media!

